

Asus P535**BenQ-Siemens C81**

BenQ-Siemens E71
BenQ-Siemens EF51
BenQ-Siemens EF91
BenQ-Siemens EL71
BenQ-Siemens M75
BenQ-Siemens M81
BenQ-Siemens P51
BenQ-Siemens S68
BenQ-Siemens S75
BenQ-Siemens SL75

E-Ten G500+

HTC 8500 Star Trek 101
HTC 9100 - Wizard 200
HTC P3300 - Artemis 100/160
HTC S310 - Oxygen
HTC S730 - Wings

HP iPAQ 514 Voice Messenger**Hummer HT 1**

LG Electronics KE500 (Shine)
LG Electronics KE820
LG Electronics KE850 (Prada)
LG Electronics KE970 Shine
LG Electronics KU580 (Chocolate Multimedia)
LG Electronics KU800
LG Electronics KU950
LG Electronics KU970 (Shine)
LG Electronics KU990

Motorola E770v

Motorola E8 (Rokr)
Motorola L9 (Motoslvr)
Motorola Moto U9
Motorola MOTOKRZR K1
Motorola MOTOKRZR K2
Motorola MOTOKRZR K3
Motorola Motorazr maxx V6
Motorola MOTOROKR Z6
Motorola Q8 (Moto)
Motorola Q9 (Moto)
Motorola RAZR V3x
Motorola RAZR V3xx
Motorola RAZR² V8
Motorola RAZR² V9
Motorola ROKR E2
Motorola V6 PEBL
Motorola W510
Motorola Z3 Motorizr
Motorola Z8 Motorizr

Nokia 2630

Nokia 2600 Classic
Nokia 2760
Nokia 3109 Classic
Nokia 3110 Classic
Nokia 3500 Classic
Nokia 5200
Nokia 5300 Xpress Music
Nokia 5310 Xpress Music

Nokia 5610 Xpress Music
Nokia 6085
Nokia 6086
Nokia 6110 Navigator
Nokia 6131
Nokia 6267
Nokia 6288
Nokia 6290
Nokia 6300
Nokia 6301
Nokia 6500 Classic
Nokia 6500 Slide
Nokia 6555
Nokia 7373
Nokia 7390
Nokia 7500 Prism
Nokia 7900 Prism
Nokia 8600 Luna
Nokia 8800
Nokia 8800 Arte
Nokia 8800 Sirocco Edition
Nokia E51
Nokia N76
Nokia N77
Nokia N81
Nokia N82
Nokia N95

Pantech PG-3700**Philips Xenium 9@9r**

Sagem my411x
Sagem my501Ci
Sagem my600x
Sagem my700X Contactless
Sagem my750c-TV
Sagem my800C
Sagem my800X
Sagem my850C
Sagem P'9521 (Porsche Design)

Samsung SGH-D520

Samsung SGH-D600
Samsung SGH-D800
Samsung SGH-D820
Samsung SGH-D830
Samsung SGH-D840
Samsung SGH-D900i
Samsung SGH-E200
Samsung SGH-E250
Samsung SGH-E380
Samsung SGH-E500
Samsung SGH-E590
Samsung SGH-E740
Samsung SGH-E760
Samsung SGH-E770
Samsung SGH-E830
Samsung SGH-E840
Samsung SGH-E870
Samsung SGH-E900
Samsung SGH-F200
Samsung SGH-F300
Samsung SGH-F310
Samsung SGH-F330
Samsung SGH-F490
Samsung SGH-F500

Samsung SGH-F700
Samsung SGH-G600
Samsung SGH-G800
Samsung SGH-i300
Samsung SGH-i320
Samsung SGH-i520
Samsung SGH-i550
Samsung SGH-i600
Samsung SGH-L760
Samsung SGH-P300
Samsung SGH-P310
Samsung SGH-P520 (Armani)
Samsung SGH-P900
Samsung SGH-P910
Samsung SGH-U100 Ultra II
Samsung SGH-U300 Ultra II
Samsung SGH-U600 Ultra II
Samsung SGH-U700 Ultra II
Samsung SGH-X700
Samsung SGH-X800
Samsung SGH-X820
Samsung SGH-X830
Samsung SGH-Z320i
Samsung SGH-Z370
Samsung SGH-Z400
Samsung SGH-Z510
Samsung SGH-Z520
Samsung SGH-Z550
Samsung SGH-Z560
Samsung SGH-Z560V
Samsung SGH-Z620
Samsung SGH-Z700
Samsung SGH-Z710
Samsung SGH-Z720
Samsung SGH-ZV50
Samsung SPH-B5000
Samsung SPH-B5050
Samsung SPH-M610

Siemens CX75**Sony Ericsson** K530i

Sony Ericsson K550i
Sony Ericsson K610i
Sony Ericsson K660i
Sony Ericsson K770i
Sony Ericsson K790i
Sony Ericsson K800i
Sony Ericsson K850i
Sony Ericsson P990i
Sony Ericsson S500i
Sony Ericsson T650i
Sony Ericsson V630i
Sony Ericsson V640i
Sony Ericsson W580i
Sony Ericsson W610i
Sony Ericsson W660i
Sony Ericsson W710i
Sony Ericsson W850i
Sony Ericsson W880i
Sony Ericsson W890i
Sony Ericsson W910i
Sony Ericsson W960i
Sony Ericsson Z610i
Sony Ericsson Z710i
Sony Ericsson Z750