Introduction

This Bluetooth headset B-Speech®Nemo is a wireless handsfree utilizing Bluetooth wireless technology. B-Speech®Nemo uses a frequency range between 2,4GHz and 2,48GHz and has a range of maximal 10 meters (Class II).

B-Speech®Nemo works with Bluetoothâ version 1.1 and 1.2 compatible mobiles. Please, make sure your mobile uses this version (see your manual). You can also find information about compatible mobiles on the internet at www.b-speech.de.

Features

1.   Battery Cover
2.   LED Display
3.   Microphone
4.   Volume Up Button/Pairing/On-Off
5.   Volume Down Button/Re-dial/Hang up
6.   Talking
7.   Lock-/Unlock Button

What's in the package?

1. One Bluetooth headset B-Speech®Nemo with ear hook

2. Five AAA Alkaline batteries

3. One user guide

4. Neck strip

Wearing preference

The headset can be worn on either side by inserting the ear hook of the headset.

You can adjust the ear hook by bending it.

Before using your Bluetooth headset B-Speech®Nemo:

Inserting the battery

    A. Unlock the battery cover back.

    B. Slide the battery cover towards and open the headset

    C. Put the battery in the headset, observing the polarity.

    D. Close and lock the battery cover.

Pairing procedure

Your B-Speech®Nemo Bluetoot headset needs to be paired to your mobile phone before it can be used. This is a two part process; one part is carried out on the headset and the other is caried out on the mobile phone. Note that different mobile phones use a different method to go trough the pairing process.

Please note that your Headset must be switched off!

1. Switch on your headset..

2. Follow the instructions in the user guide of the cell phone to activate the Bluetooth feature and find out how to invoke the Bluetooth device search.

3. Press and hold the Talk button (bigger button) on the headset for 5 seconds until both Blue LEDs blink rapidly. This indicates that the headset is in pairing mode.

4. Perform a Bluetooth device search on the cell phone. (It may take several seconds.)

5. The phone's display will advise that it has found B-Speech®Nemo and ask you to confirm that you want to pair with it. Confirm this.

6. Enter the passkey 0000 when your phone prompts you, and the phone will start the pairing

with the headset.

7. Your phone will advise you that the pairing is successfully, and the LED on your headset will change its state to show that it's now in standby mode. The blue LED will flash every 3 seconds depending on the profile your cell phone supports.

8. If the pairing fails, the blue LEDs keep blinking rapidly. Please repeat steps A to G to pair the headset and the phone again.

NOTE: The display on the mobile phone will also give the status. Once the headset and phone have been successfully paired, you are ready to make and receive calls.

Turning your headset ON and OFF

To switch your headset on, press the Talking button (the bigger one) for about 3 seconds until the blue LED quickly flash 5 times

To switch your headset off, press and hold the Talking button (the bigger one) for 3 seconds until the blue LED flashes 5 times.Then the headset will turn off.

Answering a call

If there is an incoming call, a ring tone will sound in your headset; please press theTalking button (the bigger one) on the headset to answer the call.

If your cell phone supports auto-answering, the headset will take the incoming call automatically and you don't need to press any button.

Ending a call

When in conversation, you can press and hold the Talking button (the bigger one) for 1 seconds to end the call. You can also end the call by pressing the END button on the cell phone. When the other party hangs up, the headset ends the call automatically.

–

Make a call

You can make calls from your mobile phone, or directly from the headset using

voice dialing and last number redialing (if it's supported by the phone)

To make calls from your mobile phone - Dial the call from your mobile phone and the call is automatically connected to your Headset.

To make calls using voice dialing (if supported by your mobile phone) - With the headset in standby mode, press (click) the Talk button on the Headset, and you will hear the "Voice Dial" tone (**Two short beeps**). Speak the name of the person you wish to call. The call is automatically connected to your headset.

To make calls using last number redial (if supported by your mobile phone) - Whilst in standby mode, press and hold the Volume "+" more than 4 seconds, and you will hear a "Last Number Redial" tone (**single long beep**); Release the Volume "+" button, the call is automatically connected to your mobile phone.

> **Note:** This function only works on Bluetooth phones that support Handsfree profile.

Call transfer

When in conversation, you may transfer the voice from headset to phone or from phone to headset. Press the Volume Up button for 3 seconds to make the transfer.

Note: This function only works on Bluetooth phones that support Handsfree profile.

For some cell phones (Sony Ericsson phones, for example), you can only transfer from the headset to the phone, not vice versa. If this is the case, you must end the call from the cell phone.

Speaker volume control button

To increase the volume - While in talking mode, press (click) the Volume button + to increase volume by 1 step, repeat this procedure until you have reached the desired level.

To decrease the volume - While in talking mode, press (click) the Volume button - to decrease volume by 1 step, repeat this procedure until you have reached the desired level.

Mute functiont

You can mute and un-mute the microphone temporarily so that you cannot be heard by the connected party.

To mute the headset – While in talking mode, press and hold the volume button "+" and volume button "-" concurrently more than 3 seconds, and you will hear a MUTE tone (**Single beep**), the microphone is muted.

To un-mute the headset - When microphone is muted, press and hold volume button "+" and Volume button "-" concurrently for 3 seconds, and you will hear a MUTE tone (**Single beep**), the microphone is un-muted.

Audio and visual indicators

Visual LED chart:

Headset state	Remark
Headset off mode	LED´s are off
Headset in Standby mode, ready to make and receive calls	LED`s flash 1 second alternately
Headset is in Pairing Mode	LED`s flash quickly 5 times per seconds
Headset making connection, audio connection for voice dial	LED´s flashes twice quickly at 1 second intervals
During a call	LED`s flash 2 times every second

Trouble shooting:

Status	Indication
Headset off mode	LEDs are off
Headset in standby mode, ready to make and receive calls	LEDs flash 1 second alternately
Headset is in pairing mode	LEDs flash quickly 5 times per seconds
Headset making connection, audio connection for voice dial	LEDs flashes twice quickly at 1 second intervals

Caution:

Please read the following instructions carefully before using your headset.

. Do not dismantle the headset

. Protect the headset from dust and dirt

. Do not expose the headset to high temperature

. Turn the headset off in aeroplanes and at petrol stations.

. Do not allow children access to the headset. Parts could come apart and be swallowed.

Battery advice:

Risk of explosion if battery is exposed to fire.

Do not open battery.

Do not expose battery to liquid

Do not short circuit battery, nor bring in contact with other metal

Do not let children play with batteries.

Always recicle the batteries

Dispose of used batteries according to the national regulations.

B-Speech® declares herewith that this device carries the CE mark in accordance with the regulations and standards of the guideline R&TTE (1999/5/EG). It conforms with the fundamental requirements, the appropriate regulations and rules of the guideline 1999/5/EG. You can find the complete declaration of conformity under www.b-speech.de.

Warranty and parts replacement

Dear customer,

Our B-Speech products are subject to a strict quality control. However, should you have problems, please contact your seller or www.B-Speech.de. You will then be help rapidly.

Please, note :

* The warranty is limited to the original purchaser.

* A copy of your receipt or other proof of purchase is required. Without proof of purchase, your warranty is defined as beginning on the date of manufacture as labeled on the products.

* The warranty is void if the serial number, date code label or product label is removed, or if the product has been subject to physical abuse, improper installation, modification, or repair by unauthorized third parties.

* The responsibility for our products is limited to the repair or replacement of the product at our discretion.

* All warranty on our products is limited to two years from the date of purchase.

* Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear, such as microphone, decorative finishes, batteries, and other accessories.

* We are not liable for any incidental or consequential damages arising from the use or misuse of any our products.

* This warranty gives you specific rights but you may have other rights depending on your location.

* Unless otherwise instructed in the user guide, the user may not, under any circumstances, attempt to perform service, adjustments or repairs on this unit, whether in or out of warranty. It must be returned to the sales outlet, factory or authorized service agency for all such work.

* We do not assume any responsibility for any loss or damage incurred during shipping. Any repair work on our products by unauthorized third parties nullifies any warranty.